



Fig. 55—Complete Car Wiring Diagram

1938 CHEVROLET PASSENGER CAR