



1940 Chevrolet—Passenger Car Wiring Diagram