



The only
**CUSTOM-MADE
 SEALED-BEAM**
*Fog light designed to fit
 the 1949 CHEVROLET*

Engineered and Manufactured
 Exclusively by

**WATLING SPECIALTY &
 MACHINE CO.**

4232 West Harrison Street
 CHICAGO 24, ILL.

INSTALLATION INSTRUCTIONS

1. Screw brass studs into threaded hole in back of lamp assembly and tighten with pliers.
2. Put lamps in their respective positions on the grille as in photograph.
(LTHD inside of the chrome shell refers to the left side of the car when seated in the the car.)
3. Slip brackets over brass studs, straddling horizontal grille members, and tighten nuts so that lamps are held securely.

These fog lamps are solid brass castings, heavily chromium plated. They are guaranteed to out last any other plated piece on the car.

WIRING DIAGRAM

